## aselsan

# MWCP MASTER WARNING / CAUTION PANEL





Master Warning / Caution Panel consists of two independent indicators for the annunciation to the pilot and copilot. Master Caution Rectangular Illuminated Indicator is responsible of indicating/resetting caution situations to pilot and copilot via illuminated buttons. Master Warning Rectangular Illuminated Indicator is responsible of indicating/resetting warning situations to pilot and copilot via illuminated buttons.

#### **Technical Specifications**

· Warning and Caution indication and Reset Capability

#### Interfaces

- MIL-STD-704F 28 VDC Electrical Power Interface
- · Discrete Interfaces

#### Qualifications

- MIL-STD-810 / DO-160E
- MIL-STD-704
- MIL-STD-461

#### **Physical Specifications**

Operating Temperature and Altitude

: -40°C / +55°C, 15.000 ft.

Storage Temperature

: -55°C / +85°C

### **Physical Specifications**

- Dimensions: 28 mm (H) x 180 mm (W) x 110 mm (D)
- Weight: <300 gr</li>

